

VIBRANT/BOKER SPORTS VINYL FLOOR – INSTALLATION INSTRUCTIONS

Floor must be dry, levelled & crack free.

- Measure and Plan: Measure the area and plan your layout. Start in the center of the room to ensure even cuts at the edges.
- **Cut the Vinyl:** Use a utility knife to cut the vinyl to fit your space. Make sure to leave a small expansion gap around the edges.
- Apply Adhesive (if needed): If your vinyl isn't peel-and-stick, use a trowel to spread adhesive over the subfloor according to the manufacturer's instructions.
- Install the Vinyl: Begin laying the vinyl, starting from the center and working your way out. Press down firmly and smooth out any bubbles.
- Use a Roller: After laying the vinyl, use a roller to ensure good adhesion, focusing on the seams.
- Trim Edges: Once the flooring is laid, trim any excess at the edges with a utility knife.

NOTE: 1) Boker is the brand of Vibrant Floors.

2) The flooring must be installed by professional installer.

