

VIBRANT WOVIN VINYL WALLCOVERING – INSTALLATION INSTRUCTIONS

Wall must be dry, levelled, crack free, putty & primer treated.

- **Mix Adhesive:** Follow the manufacturer's instructions to mix the wallpaper adhesive.
- **Apply Adhesive:** Using a roller or brush, apply adhesive directly to the wall or the back of the vinyl, depending on the type of adhesive used.
- **Position the First Panel:** Align the first panel against the wall, starting from a corner or a plumb line for accuracy.
- **Smooth the Panel:** Use a smoothing brush or plastic smoother to eliminate air bubbles, working from the center outwards.
- **Trim Excess:** Once the panel is in place, use a utility knife and straightedge to trim the excess at the top and bottom.
- **Install Additional Panels:** Repeat the process for subsequent panels, ensuring seams align properly. Use a steam roller to press seams together securely.
- **Clean Up:** Wipe off any excess adhesive with a damp sponge before it dries.

NOTE: The wall-covering must be installed by professional installer.